



INSTRUCTIONS

Halloween Animatronic Banjo Skeleton Combo



PARTS

01



01 SKELETON
(WITH PRE-ATTACHED CONNECTION CABLE)

02



02 SKELETON

03



03 ADAPTER



ASSEMBLY

01



If any parts are missing or damaged, do not assemble and contact customer service.

02



Place skeleton (1) and skeleton (2) on a flat, level surface, spaced generously apart as shown.



Connect the 2 skeletons



Insert the plug into the adapter




The volume control dial



Multi-lingual sounds & switch setting



Sound sensor has a decibel range of 80-85 db



Motion sensor has a range of 1m / 3.2 ft

CAUTION!

This item is not a toy. It is meant for decorative purposes only.
Contains small parts, posing a choking hazard.
This item is designed for individuals aged 15 years and above.
Not suitable for children under 14 years old.