




11FT Halloween Animatronics Flying Hovering Witch


NOTE: Assembly requires 2 people




PARTS




Bracket Base A * 1
Iron pipe A * 4



Iron pipe B * 1
Fixed Support Bar * 1




Wing nut * 1
Fixed pin * 4



Iron pipe C * 4
Plastic Crutch * 4



Broom Bucket * 1




Iron pipe D * 1
Right-hand Plastic Crutch * 1




Witch's Body * 1



Witch Head * 1
Hat * 1
Costume * 1




Iron pipe E * 1
Cotton Tube * 1
Witch Left Hand * 1




Witch's Tail Bracket * 2
U-shaped Fixing Pin * 4

ASSEMBLY

01



Downward
Insert the base




Direction
Consistent

Insert iron pipe B into the base of iron pipe A
The direction of the selected area should be consistent.


02

Assemble the fixed support bar



Insert the fixed pins into the ends of the fixed bracket.
Then, tighten the wing nut to the right to secure Iron pipe A and B.

03



Insert iron pipe C into iron pipe B


04



⚠ Be careful with the nails.

Insert the body of the broom into the installed support base bracket.


05



Iron pipe C * 4


Assemble the 4 iron pipe C parts in sequence.

06



Referring to the procedure in the last step, install the 4 plastic crutches one by one.

07



Connect iron pipe D with iron pipe C and then install the witch's right hand plastic crutch

08



Insert the witch's body parts into the clothes from top to bottom.
The clothes have an elastic band in the middle. Stretch the elastic band while inserting the witch's body.

09



Install the witch's head and connect the wires

10




Put the hat on the witch. The rubber band at the bottom of the hat goes around the head.

11



Installation of Left hand



Installation of the iron pipe E

Assemble the left hand onto the upper body. Then assemble iron pipe E into the body.

12



✓ Completed Effect



✓ Completed Effect

The witch's body and the support frame have been assembled successfully.

13

P1

⚠ ATTENTION



Total height: 11ft

Always assemble on the ground.

Two adults required for safe assembly.


Risk of tipping or injury if not assembled correctly.



Dump installation

The Witch and its supporting base bracket have been successfully installed.

14




Completion diagram



The iron pipe E on the witch's right hand is connected to the broom.

15



Unzip the Velcro on the back of the witch's clothes






Adjust volume / Switch on/off


Warm Tips: The Flying Witch supports sound and motion sensor activated. However, when the battery level is low and the voltage drops, the motion sensing function will not work, although sound activation will still function normally.

Switch On or Off for the witch and rotate to adjust the volume level. Install 3 AA batteries

16




Completion diagram



Connect the witch's 2 tail brackets to the body, then secure them with fixed pins

17

Completion
diagram


X2

Tie the middle string of the witch's clothes to the center of the tail bracket, and tie the bottom string to the end of the bracket. Then, fasten the Velcro at the end of the clothes together.

18



Raise the witch



X2

Two people work together to lift the witch
Insert the 4 * Iron pipe A into the Bracket Base A, which makes the flying witch more stable.

19



Fixed ground



X2

**ATTENTION**

If the frame is not installed on the ground, use heavy objects to secure it to prevent it from tipping over or collapsing.

Use U-shaped fixing pins to firmly fix base to the ground.

CAUTION!

This item is not a toy. It is meant for decorative purposes only.
Contains small parts, posing a choking hazard.
This item is designed for individuals aged 15 years and above.
Not suitable for children under 14 years old.